

1. The Properties of Fluids

[This material relates predominantly to modules ELP034, ELP035]

1.1 Fluids

1.2 Newton's Law of Viscosity

1.3 Fluids Vs Solids

1.4 Liquids Vs Gases

1.5 Causes of viscosity in fluids

1.7 Density

1.7 Viscosity

1.1 Fluids

There are two aspects of fluid mechanics which make it different to solid mechanics:

1. The nature of a fluid is much different to that of a solid
2. In fluids we usually deal with *continuous* streams of fluid without a beginning or end. In solids we only consider individual elements.

We normally recognise three states of matter: solid; liquid and gas. However, liquid and gas are both fluids: in contrast to solids they lack the ability to resist deformation. Because a fluid cannot resist the deformation force, it moves, it *flows* under the action of the force. Its shape will change continuously as long as the force is applied. A solid can resist a deformation force while at rest, this force may cause some displacement but the solid does not continue to move indefinitely.

The deformation is caused by *shearing* forces which act tangentially to a surface. Referring to the figure in subsection 1.3, we see the force F acting tangentially on a rectangular (solid lined) element $ABDC$. This is a shearing force and produces the (dashed lined) rhombus element $A'B'DC$.

We can then say:

A Fluid is a substance which deforms continuously, or flows, when subjected to shearing forces.


and conversely this definition implies the very important points that:

***If a fluid is at rest there are no shearing forces acting.
All forces must be perpendicular to the planes on which they are acting.***

When a fluid is in motion shear stresses are developed if the particles of the fluid move relative to one another. When this happens adjacent particles have different velocities. If


fluid velocity is the same at every point then there is no shear stress produced: the particles have zero *relative* velocity.

Consider the flow in a pipe in which water is flowing. At the pipe wall the velocity of the water will be zero. The velocity will increase as we move toward the centre of the pipe. This change in velocity across the direction of flow is known as velocity profile and shown graphically in the figure below:



Velocity profile in a pipe.

Because particles of fluid next to each other are moving with different velocities there **are** shear forces in the moving fluid i.e. shear forces are **normally** present in a moving fluid. On the other hand, if a fluid is a long way from the boundary and all the particles are travelling with the same velocity, the velocity profile would look something like this:




Velocity profile in uniform flow

and there will be no shear forces present as all particles have zero relative velocity. In practice we are concerned with flow past solid boundaries; aeroplanes, cars, pipe walls, river channels etc. and shear forces will be present.

1.2 Newton's Law of Viscosity

How can we make use of these observations? We can start by considering a 3d rectangular element of fluid, like that in the figure below.



Fluid element under a shear force

The shearing force F acts on the area on the top of the element. This area is given by $A = \delta z \times \delta x$. We can thus calculate the *shear stress* which is equal to force per unit area i.e.

$$\text{shear stress, } \tau = \frac{F}{A}$$

The deformation which this shear stress causes is measured by the size of the angle ϕ and is known as *shear strain*.

In a solid shear strain, ϕ , is constant for a fixed shear stress τ

In a fluid ϕ increases for as long as τ is applied - the fluid flows.

It has been found experimentally that the *rate of shear strain* (shear strain per unit time, τ/time) is directly proportional to the shear stress.

If the particle at point E (in the above figure) moves under the shear stress to point E' and it takes time t to get there, it has moved the distance x . For small deformations we can write

$$\text{shear strain } \phi = \frac{x}{y}$$

$$\begin{aligned} \text{rate of shear strain} &= \frac{\phi}{t} \\ &= \frac{x}{ty} = \frac{x}{t} \frac{1}{y} \\ &= \frac{u}{y} \end{aligned}$$

where $\frac{x}{t} = u$ is the velocity of the particle at E.

Using the experimental result that shear stress is proportional to rate of shear strain then

$$\tau = \text{Constant} \times \frac{u}{y}$$

The term $\frac{u}{y}$ is the change in velocity with y , or the velocity gradient, and may be written in the differential form $\frac{du}{dy}$. The constant of proportionality is known as the dynamic viscosity, μ , of the fluid, giving

$$\tau = \mu \frac{du}{dy}$$

This is known as **Newton's law of viscosity**.

1.3 Fluids vs. solids

In the above we have discussed the differences between the behaviour of solids and fluids under an applied force. Summarising, we have;

- 1 ***For a solid the strain is a function of the applied stress (providing that the elastic limit has not been reached). For a fluid, the rate of strain is proportional to the applied stress.***
- 2 ***The strain in a solid is independent of the time over which the force is applied and (if the elastic limit is not reached) the deformation disappears when the force is removed. A fluid continues to flow for as long as the force is applied and will not recover its original form when the force is removed.***

It is usually quite simple to classify substances as either solid or liquid. Some substances, however, (e.g. pitch or glass) appear solid under their own weight. Pitch will, although appearing solid at room temperature, deform and spread out over days - rather than the fraction of a second it would take water.

As you will have seen when looking at properties of solids, when the elastic limit is reached they seem to flow. They become plastic. They still do **not** meet the definition of true fluids as they will only flow after a certain minimum shear stress is attained.

1.4 Liquids vs. Gases

Although liquids and gasses behave in much the same way and share many similar characteristics, they also possess distinct characteristics of their own. Specifically

- A liquid is difficult to compress and often regarded as being incompressible. A gas is easily to compress and usually treated as such - it changes volume with pressure.
- A given mass of liquid occupies a given volume and will occupy the container it is in and form a free surface (if the container is of a larger volume). A gas has no fixed volume, it changes volume to expand to fill the containing vessel. It will completely fill the vessel so no free surface is formed.

1.5 Causes of viscosity in fluids

Viscosity in Gases

The molecules of gasses are only weakly kept in position by molecular cohesion (as they are so far apart). As adjacent layers move by each other there is a continuous exchange of molecules. Molecules of a slower layer move to faster layers causing a drag, while molecules moving the other way exert an acceleration force. Mathematical considerations of this momentum exchange can lead to Newton law of viscosity.

If temperature of a gas increases the momentum exchange between layers will increase thus increasing viscosity.

Viscosity will also change with pressure - but under normal conditions this change is negligible in gasses.

Viscosity in Liquids

There is some molecular interchange between adjacent layers in liquids - but as the molecules are so much closer than in gasses the cohesive forces hold the molecules in place much more rigidly. This cohesion plays an important roll in the viscosity of liquids. Increasing the temperature of a fluid reduces the cohesive forces and increases the molecular interchange.

1.6 Density

The properties outlines below are general properties of fluids which are of interest in engineering. The symbol usually used to represent the property is specified together with some typical values in SI units for common fluids. Values under specific conditions (temperature, pressure etc.) can be readily found in many reference books. The dimensions of each unit is also give in the MLT system (see later in the section on dimensional analysis for more details about dimensions.)

Density

The density of a substance is the quantity of matter contained in a unit volume of the substance. It can be expressed in three different ways:

Mass Density, ρ , is defined as the mass of substance per unit volume.

Units: Kilograms per cubic metre, (kg/m^3 or kgm^{-3})

Dimensions: ML^{-3}

Typical values:

Water = 1000 kgm^{-3} , Mercury = 13546 kgm^{-3} Air = 1.23 kgm^{-3} , Paraffin Oil = 800 kgm^{-3} .

(at pressure = $1.013 \times 10^{-5} \text{ Nm}^{-2}$ and Temperature = 288.15 K.)

Specific Weight ω , (sometimes γ , and sometimes known as *specific gravity*) is defined as the weight per unit volume.

or

The force exerted by gravity, g , upon a unit volume of the substance.

The Relationship between g and ω can be determined by Newton's 2nd Law, since
weight per unit volume = mass per unit volume g

$$\omega = \rho g$$

Units: Newton's per cubic metre, N/m^3 (or Nm^{-3})

Dimensions: $ML^{-2}T^{-2}$

Typical values:

Water = $9814 Nm^{-3}$, Mercury = $132943 Nm^{-3}$, Air = $12.07 Nm^{-3}$, Paraffin Oil = $7851 Nm^{-3}$

1.7 Viscosity

Viscosity, μ , is the property of a fluid, due to cohesion and interaction between molecules, which offers resistance to shear deformation. Different fluids deform at different rates under the same shear stress. Fluid with a high viscosity such as syrup, deforms more slowly than fluid with a low viscosity such as water.

All fluids are viscous, "Newtonian Fluids" obey the linear relationship

given by Newton's law of viscosity. $\tau = \mu \frac{du}{dy}$, which we saw earlier.

where τ is the shear stress,

Units Nm^{-2} ; $kg m^{-1}s^{-2}$

Dimensions $ML^{-1}T^{-2}$.

$\frac{du}{dy}$ is the velocity gradient or rate of shear strain, and has

Units: $radians s^{-1}$,

Dimensions t^{-1}

μ is the "coefficient of dynamic viscosity" - see below.

Coefficient of Dynamic Viscosity

The Coefficient of Dynamic Viscosity, μ , is defined as the shear force, per unit area, (or shear stress τ), required to drag one layer of fluid with unit velocity past another layer a unit distance away.

$$\mu = \tau \frac{du}{dy} = \frac{\text{Force}}{\text{Area}} \frac{\text{Velocity}}{\text{Distance}} = \frac{\text{Force} \times \text{Time}}{\text{Area}} = \frac{\text{Mass}}{\text{Length} \times \text{Area}}$$

Units: Newton seconds per square metre, Nsm^{-2} or Kilograms per meter per second, $kgm^{-1}s^{-1}$

(Although note that μ is often expressed in Poise, P, where $10 P = 1 kgm^{-1}s^{-1}$)

Typical values:

Water = $1.14 \times 10^{-3} kgm^{-1}s^{-1}$, Air = $1.78 \times 10^{-5} kgm^{-1}s^{-1}$, Mercury = $1.552 kgm^{-1}s^{-1}$, Paraffin Oil = $1.9 kgm^{-1}s^{-1}$

Kinematic Viscosity

Kinematic Viscosity, ν , is defined as the ratio of dynamic viscosity to mass density.

$$\nu = \frac{\mu}{\rho}$$

Units: square metres per second, m^2s^{-1}

(Although note that ν is often expressed in Stokes, St, where $10^4 St = 1 m^2s^{-1}$.)

Dimensions: L^2T^{-1} .

Typical values:

Water = $1.14 \times 10^{-6} m^2s^{-1}$, Air = $1.46 \times 10^{-5} m^2s^{-1}$, Mercury = $1.145 \times 10^{-4} m^2s^{-1}$, Paraffin Oil = $2.375 \times 10^{-3} m^2s^{-1}$

$$R_x = -F_{t_x} = -233.44 N$$

$$R_y = -F_{t_y} = -1324.6 N$$